ArcticChill 88 Exceptional Capacity Direct Chill

- Direct chill cold water cooler
- Single dispensing button for chilled water
- Can be fitted with overflow kits & mains drainage
- Fits our standard cowling and wall bracket
- WRAS approved
- FloodGuard inlet solenoid protects the cooler against large scale flooding
- Impressive 23cm dispensing height
- The Klaran UVC LED Shield available.Designed to destroy bacteria and viruses to protect your health
- Contactless dispensing option available to avoid touch contamination



23cm Dispensing Height To Fill Bottles

ERCTIC CHILLSS CONTRACTOR

Description	Dimensions H X W X D (MM)	Weight (Kg)
POU Floor Standing	1135 x 340 x 340	25
POU Table Top	460 x 340 x 340	16



refreshingly different

Delivers 30 - 40 Litres Per Hour Of Chilled Water Below 12°C

ArcticChill 88 Exceptional Capacity Direct Chill

Accessories For The ArcticChill 88

A Pumped Main Drainage System Pumps The Waste Water From The Drip Tray Over A Distance Of 100m & A Rise Of 5m. (Factory Installed).



Cowling To Fix The Cooler Securely To The Wall (Supplied Separately).



10 Litre Overflow System With Alarm To Signal When Full . (Factory Fitted).

3 Litre Overflow Kit Connects The Drip Tray To A 3 Litre Alarmed Overflow Container. The Container Has A Tap To Empty Without Removing It.



Filter Housing With Carbon Block Candle & Nanofilter.

Installation Rail With Filter. Includes Compression Fitting, 1-Micron Green Filter, Water Block, Copper Pressure Reducing Valve & Non-Return Valve.





FloodGuard - Inlet Solenoid Only Opens To Allow Water Into The Cooler, When Water Is Dispensed. By Remaining Closed All Other Times It Protects The Cooler Against Leaks.



Mains Drainage - Connect The Drip Tray To Mains Drainage. Can Be Supplied With A Pump, To Pump The Water Over 50m & A Rise Of 5m.









www.aafirst.co.uk