

ArcticChill 98 Water Cooler Parts List

No	Description	Code	Remarks
1	TOP COVER POU	WB3301	
2	FRONT LENS		See WB9807
3,4	DRIP TRAY COMPLETE	WB4454N	
4	DRIP TRAY GRILL	WB4419	
5	HYGIENE GUARD	WB8819	
6	UPPER FRONT PANEL	WB9801N	
2,7, 8,28,34	PUSH BUTTON FACIA COMPLETE (ambient/cold)	WB9807	
8	PUSH BUTTON		See WB9807
9	ADJ.FOOT	WB3326	
11	COLD TANK BRACKET	WB100C11	
12	SIDE PANEL F STANDING	WB3305	
14	BASE FLOOR STANDING	WB3310	
15	SOLENOID BRACKET	WB100C15	
16	LOWER FRONT PANEL	WB3307	
17	FILTER/DRIER	WB100C17	
18	CONDENSER	WB9818	
19	WIRING LOOM	WB9819	
20	MAINS LEAD	WB3333	
21	MAINS SOCKET	WB3348	
22	COLD ON/OFF SWITCH (BLACK)	WB100C22	1 NEEDED
23	TANK INLET SOLENOIDS (COLD)	WB100C23	
24	INLET SOLENOID	WB4486	
25	OUTLET DOUBLE SOLENOID	WB100C25	
26	TRANSFORMER	WB7032	
27	MAIN PCB	WB9827	
28	DISPENSING PCB		See WB9807
29	LED PCB	WB9829	
30	PCB BRACKET	WB7030	
31	PCB COVER	WB7031	
32	PUSH BUTTON SPRING	WB8812	
33	TOP COVER FIXINGS	WB3325	
34	TOUCH BUTTON PADS		See WB9807
35	COLD TANK ASSEMBLY	WB100C35	
36	COMPRESSOR	WB8814	
37	LOWER FACIA BLANKING	WB332733	
38	SUB PAD	WB100C38	
39	LED WINDOW	WB5518	
40	WHITE WINDOW FOR AMBIENT	WB9840	
41	PRESSURE RELIEF VALVE	WB7053	
42	COLD TANK DRAIN COVER	WB100C42	
43	AIR VALVE	WB7025	
6A	98CLKIT COMPLETE	98CLKIT	Contactless Kit



44	INLET REDUCING VALVE	WB100C44	
45	SUPPORT BRACKET	WB5551	
46	TANK SHELF	WB100C46	
47	LOW PANEL FIXING SPRING	WB3308	
48	INLET VALVE PAD	WB100C48	
49	INLET VALVE BRACKET	WB100C49	
59	PCB BRACKET FIXINGS	WB100C59	



