

NEW

ArcticChill 109

High Capacity Cooler Dispensing Chilled & Ambient Water With An Exceptional Dispensing Height of 29cm.

- The ArcticChill109 is identical in performance to the successful ArcticChill98. One main change is a new upper front panel with an increased dispensing height of 29cm.
- Simple dispensing sequence for chilled and ambient water, using touch buttons on the upper front panel.
- The ArcticChill109 is now also available as a Table Top unit.
- Chiller capacity: 30 - 40 ltrs of below 12°C chilled water/hour.
- High Capacity Direct Chill Cooler dispensing Chilled & Ambient Water.
- FloodGuard inlet solenoid flood protection.
- Can be fitted with Overflow Kits & Mains Drainage.
- Fits AA Cooler Cowling & Wall Bracket.
- Stylish design in Anthracite livery.

Delivers 30 – 40 Ltr per Hour of Chilled Water & Unlimited Ambient Water

For optimum flow rate the mains water pressure at the point of entry into the Cooler should be around 3.5 bar



29cm Dispensing Height To Fill Sports Bottles



Description	Hourly Output		Dimensions H x W x D (mm)	Weight (Kg)
	Chilled	Ambient		
Floor Standing	30-40 Ltrs/Hr	Unlimited	1140 x 340 x 350	25
Table Top	30-40 Ltrs/Hr	Unlimited	460 x 340 x 340	16

AA FIRST
WATER COOLERS
& BOILERS



Quality – Reliability – Integrity

NEW

ArcticChill 109

High Capacity Cooler Dispensing Chilled & Ambient Water With An Exceptional Dispensing Height of 29cm.

Press & hold the dispensing button



To dispense AMBIENT water, TOUCH the symbol to select, then press & hold the dispensing button.
(the light will flash green when selected/dispensing)

To dispense CHILLED water, press & hold the dispensing button.
(The chilled light will flash blue during dispensing)

POWER / COOLING light indicates power is on.
Blue indicates cooling in progress.
White indicates the cooler is ready.



Accessories For The ArcticChill 109

Installation rail with filter.
Includes compression fitting, 1-Micron green filter, water block, copper pressure reducing valve & non-return valve



FloodGuard - closed inlet solenoid only opens to allow water into the cooler, when water is dispensed. By remaining closed all other times it protects the cooler against leaks



The KLARAN UVC LED Shield protects Direct Chill Water Coolers from Bacteria, Viruses & other Pathogens providing point of dispense protection. Factory Fitted or Self Installed options.



Mains drainage - connect the drip tray to mains drainage.



Cowling to fix the cooler securely to the wall. (Supplied separately)



10 litre overflow system with alarm to signal when full. (Factory fitted)



3 Litre overflow kit connects the drip tray to a 3 litre alarmed overflow container. The container has a tap to empty without removing it



A pumped main drainage system pumps the waste water from the drip tray over a distance of 100m & a rise of 5m. (Factory installed)

