## **ArcticRevolution 75B**

An Outstanding New Design With Increased Fuctionality. (To replace the AcrcticRevolution 70/70B)



## Functionality

- The ArcticRevolution 75B represents a significant UPGRADE in design and functionality which replaces the ArcticRevolution 70/70B.
- A Direct Chill Table Top Cooler dispensing ambient & chilled water.
- Can be fitted with a KLARAN UVC LED self sanitising processor and a contactless kit to stop hand to tap contamination.
- Narrow footprint for small worktop spaces and low height to fit under overhanging kitchen cupboard.
- R600a gas.
- Dispensing height of 26.5cm.
- Hourly chilled capacity of 10ltr.
- Flood Guard inlet solenoid protects against large scale flooding.
- Hygiene Guard reduces the risk of contamination of the dispensing nozzle.
- High quality build by Wonbong.

Description	Dimensions H X W X D (MM)	Weight (Kg)
POU Table Top	373 x 240 x 488	14



Quality - Reliability - Integrity

# **ArcticRevolution 75B**

An Outstanding New Design With Increased Fuctionality. (To replace the ArcticRevolution 70/70B)

### **Dispensing Ambient or Chilled Water**

#### **Dispensing Ambient Water**


- Select Ambient Water Selection Button and then touch the Dispensing Button to dispense Ambient Water. When you remove your finger from the Dispensing Button, dispensing stops.
- The droplet in the center of the panel will pulsate in grey during dispensing

#### **Dispensing Chilled Water**

- Select Cold Water Selection Button and then touch the Dispensing Button to dispense Cold Water. When you remove your finger from the Dispensing Button, dispensing stops.
- The droplet in the center of the panel will pulsate in blue during dispensing.

#### **Dispensing Using Contactless Option**

Place your hand 5 to 10cm in front of the contactless sensor to dispense.



### Accessories



Installation Rail with FILTER XL In-Line Filter.



Installation rail with green Filter Housing and green Carbon Block Filter Candle or green nanofilter Candle.



FloodGuard - Inlet solenoid only opens to allow water into the cooler, when water is dispensed. By remaining closed all other times it protects the cooler against leaks.



Quality - Reliability - Integrity